


New Third Rack Dishwashers

Introducing the all new Bosch dishwasher collection, featuring 3rd racks across all 300, 500, 800 Series models, adding 30% more loading area without sacrificing it elsewhere.



- Accommodates larger, deeper items like 6" x 2.5" cereal bowls.
- Angled to allow for 9" wine glass in upper rack.
- Fits dinner plates up to 11.5"*.
*When upper rack is tilted using RackMatic® function
- Frees up space below for larger items like stock pots.

With the industry's largest 3rd rack loading capacity,¹ MyWay™ frees up more room in the bottom rack for larger items like pots, colanders and baking sheets.

¹ Vs. major brands with 3rd rack. Major brands defined as TraQline Top 10 Market Share, June 2016.



Standard 3rd rack

Provides the perfect space for flatware, large utensils, measuring cups, or nearly anything else that's difficult to fit in a traditional dishwasher, while its V shape leaves room below both sides for taller items like stemware in the middle rack. Available on all 300 Series models.



Flexible 3rd rack

Expandable wings easily lower to accommodate more of your deeper items, while adjustable tines let you customize the rack's loading space to fit awkward or bulky utensils. Available on all 500 and 800 Series models.



MyWay™ rack

MyWay™ offers more room for more kinds of items in the top rack, such as cereal bowls, whisks, tongs and large measuring cups, creating more freedom in loading below. Available on all 800 Series Premium models.



EasyGlide™ rack system

For a level of quality you can both touch and feel, we've incorporated smooth-rolling ball bearings to our rack wheels. The result is a smoother glide that opens effortlessly—even with a fully loaded rack—for a more premium feel with every pull.



Rack-mounted detergent tray

Optimized for tablets, our detergent tray holds tabs in place for a dedicated spray jet to directly dissolve them completely. This not only results in a deeper clean, it also helps to reduce unwanted noise since there's no water jet spraying the inner door. (Dishwasher also works with powder and gel.)



Sensor wash system

This state-of-the-art system uses an advanced scanning-eye sensor to literally look at the level of soil in the wash water, and adjusts both the water temperature and length of the wash cycle to eliminate redeposits. It can also determine if a secondary, fresh water fill is necessary, deleting the cycle whenever appropriate to save water and energy.



FlexSpace™ tines

This convenient new feature lets you fold back every other tine in one simple step, so it's easier to fit your largest, bulkiest items. Available on lower racks in 300 Series models and up, it helps to hold pots and pans upright, leaving more room for your other dishes.



RackMatic® adjustable rack

This remarkable middle rack easily raises or lowers in just one step, even when full. Designed to allow taller items like stemware to fit in the middle rack while leaving room for pots and pans below, it offers three different heights and up to nine separate rack positions.

Extra Dry option*

Extra Dry option increases the temperature in the final rinse, delivering enhanced drying results.

Speed60® cycle*


Enjoy your next dinner party even more knowing our Speed60® cycle can have your glasses and dishes clean and dry in about 60 minutes.

For more information on the entire line of New Third Rack Dishwashers, visit www.AskBoschSears.com. Quickly access and download spec sheets for all Bosch products including the New Third Rack Dishwashers by texting the model number to 21432

The Quietest dishwasher brand in the U.S.¹

With models as low as 39 dBA, Bosch is the quietest dishwasher brand in the U.S.¹ To reach these new heights of silence, Bosch engineers approached noise reduction from every angle, incorporating 18 unique sound-reducing technologies.

¹Based on an average of sound ratings for 24" full-size stainless steel tub dishwashers contained in major brands' websites. Major brands defined as TraQline Top 5 Market Share, June 2016.



Bosch Dishwasher Step-Up Guide

Find a complete dishwasher assortment on Sears.com/Bosch.



300 Series	500 Series	800 Series	800 Series Premium
	+ Pocket Handle Design	+ Quieter	+ Quieter
	+ EasyGlide Upper Rack	EasyGlide Upper Rack	EasyGlide Upper Rack
Standard Third Rack	+ Flexible Third Rack	Flexible Third Rack	+ MyWay™ Rack
FlexSpace Tines Lower Rack	FlexSpace Tines Lower Rack	FlexSpace Tines Lower Rack	FlexSpace Tines Lower Rack
24/7 AquaStop®	24/7 AquaStop®	24/7 AquaStop®	24/7 AquaStop®
Long SilverWare Basket	Long SilverWare Basket	Long SilverWare Basket	Long SilverWare Basket
16 Place Settings	16 Place Settings	16 Place Settings	16 Place Settings
3 Step RackMatic® Adjustable System	3 Step RackMatic® Adjustable System	3 Step RackMatic® Adjustable System	3 Step RackMatic® Adjustable System
InfoLight® **	InfoLight® **	InfoLight® **	InfoLight® **
Push Button Control	Push Button Control	+ Touch Control	Touch Control
5 Cycles / 4 Options	+ 5 Cycles / 5 Options	+ 6 Cycles / 5 Options	+ 6 Cycles / 6 Options
Deeper SS tub	Deeper SS tub	Deeper SS tub	Deeper SS tub

Standard Third Rack ADA & 18" options available 44 dBA	Flexible Third Rack 44 dBA	Touch Control ADA & 18" options available 42 dBA	MyWay™ Rack 39 dBA
---	--------------------------------------	---	------------------------------

*Available on all models ** SHX/P/V/S Only